

Settings changes do not take effect until the "Save & Enable Changes" button is pressed

Save & Enable Changes

Abandon Changes

Login

Machine Information

Location	<input type="text" value="Machine Location"/>	Machine ID	<input type="text" value="Machine ID"/>
Machine Name	<input type="text" value="Machine Name"/>	Measurement Point	<input type="text" value="Measurement Point"/>

Sensor Input

Sensor Type	<input type="text" value="Acceleration"/>	IEPE Power	<input type="text" value="Enabled"/>
Sensitivity (mV/g)	<input type="text" value="100"/>	Serial Number	<input type="text" value="Sensor Serial Number"/>
Averaging Time	<input type="text" value="1 sec"/>		

Frequency Range

F max	<input type="text" value="5 kHz"/>	F min	5 Hz
-------	------------------------------------	-------	------

Sensor Band Configuration

	Output Type	F start (Hz)	F stop (Hz)	Detector Type
Band 1	<input type="text" value="Velocity"/>	<input type="text" value="5"/>	<input type="text" value="5000"/>	<input type="text" value="RMS"/>
Band 2	<input type="text" value="Acceleration"/>	<input type="text" value="5"/>	<input type="text" value="5000"/>	<input type="text" value="RMS"/>

Measurement Results

	Result Unit	Present Level
Band 1	<input type="text" value="in/sec"/>	1.000 in/sec
Band 2	<input type="text" value="g"/>	1.000 g
True Peak	<input type="text" value="g"/>	1.417 g
Temperature	<input type="text" value="Fahrenheit"/>	32.0 °F
BOV	Volts	12.1 Volts

Current Loops

	Loop Source	Full Scale	Level	Destination	Force Loop	Force Value (mA)
Loop A	<input type="text" value="Band 1"/>	<input type="text" value="5"/>	in/sec 7.20 mA	<input type="text" value="Loop A Dest"/>	<input type="checkbox"/>	<input type="text" value="10"/>
Loop B	<input type="text" value="Disabled"/>	<input type="text" value="5"/>	0.00 mA	<input type="text" value="Loop B Dest"/>	<input type="checkbox"/>	<input type="text" value="10"/>

Network Configuration

IP Address	<input type="text" value="192.168.0.100"/>	Subnet Mask	<input type="text" value="255.255.255.0"/>
Default Gateway	<input type="text" value="192.168.0.1"/>	MAC Address	00:50:C2:19:BF:FB

Module Information

Model	iT300	Hardware Revision	D8
Serial Number	ENG2	Firmware Revision	1.01

Change Password

Load Configuration from File

Save Configuration to File

Restore Factory Defaults

Update Firmware