

Settings changes do not take effect until the "Save & Enable Changes" button is pressed

Save & Enable Changes

Abandon Changes

Login

Machine Information

Location Machine ID
 Machine Name Measurement Point

Sensor Input

Sensor Type IEPE Power
 Sensitivity (mV/g) Serial Number
 Averaging Time

Frequency Range

F max F min

Sensor Band Configuration

	Output Type	F start (Hz)	F stop (Hz)	Detector Type
Band 1	<input type="text" value="Velocity"/>	<input type="text" value="5"/>	<input type="text" value="5000"/>	<input type="text" value="RMS"/>
Band 2	<input type="text" value="Acceleration"/>	<input type="text" value="5"/>	<input type="text" value="5000"/>	<input type="text" value="RMS"/>

Measurement Results and Alarms

	Result Unit	Present Level	Low Limit Enable	Low Limit Value	High Limit Enable	High Limit Value	Result Status	Alarm Status	Map to Relay
Band 1	<input type="text" value="in/sec"/>	1.000 in/sec	<input type="checkbox"/>	<input type="text" value="0"/>	<input type="checkbox"/>	<input type="text" value="500"/>	Disabled	OK	<input type="checkbox"/>
Band 2	<input type="text" value="g"/>	1.000 g	<input type="checkbox"/>	<input type="text" value="0"/>	<input type="checkbox"/>	<input type="text" value="500"/>	Disabled	OK	<input type="checkbox"/>
True Peak	<input type="text" value="g"/>	1.417 g	<input type="checkbox"/>	<input type="text" value="0"/>	<input type="checkbox"/>	<input type="text" value="500"/>	Disabled	OK	<input type="checkbox"/>
Temperature	<input type="text" value="Fahrenheit"/>	32.0 °F	<input type="checkbox"/>	<input type="text" value="32"/>	<input type="checkbox"/>	<input type="text" value="248"/>	Disabled	OK	<input type="checkbox"/>
BOV	Volts	12.0 Volts	<input checked="" type="checkbox"/>	<input type="text" value="5"/>	<input checked="" type="checkbox"/>	<input type="text" value="16"/>	OK	OK	<input type="checkbox"/>

Alarm Delay Time (sec) Relay Status
 Alarm Hold Time (sec) Clear Alarms Force Relay

Current Loops

	Loop Source	Full Scale	Level	Destination	Force Loop	Force Value (mA)
Loop A	<input type="text" value="Band 1"/>	<input type="text" value="5"/>	in/sec 7.20 mA	<input type="text" value="Loop A Dest"/>	<input type="radio"/> <input type="checkbox"/>	<input type="text" value="10"/>
Loop B	<input type="text" value="Disabled"/>	<input type="text" value="5"/>	0.00 mA	<input type="text" value="Loop B Dest"/>	<input type="radio"/> <input type="checkbox"/>	<input type="text" value="10"/>

Network Configuration

IP Address Subnet Mask
 Default Gateway MAC Address

Modbus/RS485

Slave Address Format
 Baud Rate Parity

Module Information

Model iT301 Hardware Revision D3
 Serial Number ENG1 Firmware Revision 1.01

Change Password

Load Configuration from File

Save Configuration to File

Restore Factory Defaults

Update Firmware